

*See the author list of E. Joffrin et al. 2019 Nucl. Fusion 59 112021







Measurement and Modeling of Fast Ion Losses in JET Plasmas

P. J. Bonofiglo

Princeton Plasma Physics Laboratory, Princeton, NJ - USA

Acknowledgements: M. Podestà, V. Kiptily, R. Ellis, A. Horton, P. Beaumont, V. Goloborodko, F. E. Cecil, and JET Contributors*

> **EP Group Meeting** August 19, 2020

Princeton Plasma Physics Laboratory, Princeton, NJ - USA



JET Will Conduct a DT-Campaign Next Year

- Confinement of DT fusion born alphas is critical for self-heating of the plasma and achieving a burning reactor plasma
- The last DT-campaign was on JET in 1997 while ITER DT-operations are estimated for 2035!
- There is still much to learn about the confinement and transport of a fusion born alpha population which differs significantly from an externally heated ion population

Goals:

- 1. Prepare fast ion diagnostics on JET and evaluate their performance for alpha measurements
- Use discharges in the JET D-campaign for validity testing for predictive fast ion models
- 3. Develop a framework for modeling alpha transport and losses (i.e. synthetic diagnostic)




Overview

- Measurement
 - Faraday cup fast ion loss detector array
 - Recent upgrades and results
- Modeling
 - Overall Methodology
 - Integration of synthetic detector measurements
- Conclusion & Ongoing/Future Work




JET Possesses an Advanced Diagnostic Suite for Measuring Energetic Particle Activity

Neutron and Gamma Cameras and Spectroscopy




Scintillator Fast Ion Loss Detector




Other Useful JET Diagnostics

- Neutral particle analyzers
- TAE antennae
- Edge magnetic coils
- Reflectometry
- Interferometry
- SXR
- ECE

Faraday Cup Fast Ion Loss Detector Array*





Faraday Cups

*Darrow RSI 2004, 2006, 2010

PPPL is Responsible for an Array of 5 Faraday Cup Fast Ion Loss Detectors*

<u>General</u>

- Foil stacks are alternating layers of Ni and mica
- Ion energy determines deposition depth → Can't identify ion species
- Only way to differentiate ions is through modelling
- Nomenclature: Signal ID = Pylon #, Bin #, Foil #
 e.g. 213 = 2nd pylon from top, 1st radial bin, 3rd foil deep


Ni Foils

Mica Insulators

Energy Range per Foil[†]

Radial Bins

Depth (μm)	Proton Energy Range (Mev)	Deuteron Energy Range (Mev)	Triton Energy Range (Mev)	He3 Energy Range (Mev)	Alpha Energy Range (Mev)
0.0 – 2.5	0.0 - 0.49	0.0 - 0.49	0.0 - 0.50	0.0 – 1.55	0.0 – 1.54
5.0 – 7.5	0.68 - 0.96	0.79 - 1.10	0.84 - 1.20	2.30 – 3.35	2.48 – 3.55
10.0 – 12.5	1.10 – 1.32	1.35 – 1.60	1.48 – 1.76	3.90 – 4.70	4.17 – 5.09
15.0 – 17.5	1.45 – 1.65	1.78 – 2.00	2.00 – 2.25	5.20 - 5.80	5.60 - 6.35





*Darrow RSI 2004, 2006, 2010

[†]Found via SRIM code

Previous Measurements have been Fruitful but Severe Hardware Limitations have Hindered Advanced Analysis

Detector Limitations

- 1. Large amount of foil-to-foil and foil-to-machine shorts
- 2. High freq. noise pickup from ambient surroundings
- 3. Amplifier noise and breaking
- 4. Limited analysis -> 5 kHz sampling rate

Old Acquisition

- 16-bit, bipolar linear amps
- $\pm 200 \,\mu$ A range
- 5 kHz sampling rate ADC



Recent Hardware Upgrades have been Performed to Remediate Past Issues

Detector Limitations

- 1. Large amount of foil-to-foil and foil-to-machine shorts
- 2. High freq. noise pickup from ambient surroundings
- 3. Amplifier noise and breaking
- 4. Limited analysis -> 5 kHz sampling rate

Old Acquisition

- 16-bit, bipolar linear amps
- $\pm 200 \,\mu$ A range
- 5 kHz sampling rate ADC

Recent Upgrades*

- 1. Installed thicker foils in a 4-stack design to prevent foil-to-foil shorts
- 2. Installed superscreen cabling to hinder ambient noise pickup
- 3.–4. New 200 kHz ADC and amplifiers

New Acquisition


- 16-bit, bipolar linear amps
- $\pm 2000 \,\mu\text{A}$ range
- 200 kHz sampling rate ADC
- Each channel is fully controllable via software





*Bonofiglo RSI 2020

The Foil Stacks are Susceptible to Capacitive Plasma Pickup


- The front foil is plasma facing and couples to MHD activity*. The foils can then capacitively couple to one another
 allowing noise pickup to traverse the stack
- Impossible to distinguish resonant fast ion losses from pickup noise
- We assume dominant coupling is on first foil and subtract it from deeper signals







Faraday Cup Signals are Strongly Correlated with Modulated ICRH Input power




- MeV scale ICRH heated deuterium NBI ions (as well as DD fusion products) act as a proxy for fusion born DT alpha particles in deuterium plasmas
- The Faraday cup signals (left) are correlated with modulated ICRH input power indicative of heated deuteron losses
- Visible in old and upgraded detector array


Shot 94083 – Without upgrades Shot 96536 – With upgrades



Diagnostic Upgrades have Resulted in Enhanced Measurements of Fast Ion Losses*





(a.) Magnetic Mirnov coil(b.) Faraday cup foil



(a.) Magnetic Mirnov coil

- (b.) Scintillator probe PMT
- (c.) Faraday cup foil







Midway Overview

- Measurement
 - Faraday cup fast ion loss detector array
 - Recent upgrades and results
- Modeling


8/19/20

- Overall Methodology
- Integration of synthetic detector measurements
- Conclusion & Ongoing/Future Work



11

Can Combine Existing Codes to Form a Fully Integrated Model for Fast Ion Transport Validated by Experimental Measurements





Equilibrium is Provided by EFIT but Often Needs Further Constraining

- Standard equilibrium is pressure constrained EFIT
- MSE available but not on every discharge...
- Often need to better constrain the EFITs with measurements, TRANSP analysis, or other models

Shot 96133 Example w/ST

- 1. ΔT_e calculated across crash for every ECE and SXR channel
- 2. Map inversion radius (ΔT_e =0) to pol. flux
- 3. Adjust initial q-profile in TRANSP to match








Perturbations Follow Analytical Models Constrained by Measurements and ORBIT Calculations


- ORBIT takes displacement vector as input
- Structure is up to best known interpretation...
- Mode amplitude found by adjusting ORBIT calculated kicks to match measured neutron rate

Sawtooth Radial Structure*

$$f_{11}(x) = \frac{1}{2} \{1 - \tanh [\delta(x - x_s)]\},$$

$$f_{22}(x) = \begin{cases} \cos^2 \left[\frac{\pi}{2} \left(\frac{x - x_{22}}{x_{22}} \right) \right] + \frac{e^{-x^2 / x_{22}^2}}{4}, & x \le 2x_2 \\ 0, & x > 2x_2 \end{cases}$$







*Farengo NucFus 2013, Kim Nucfus 2018

Detector Measurements are Connected to the Model by Integrating Loss Orbits Backward*

0.95 MeV Lost Deuteron Orbit.






• Initial conditions: equilibrium, Faraday cup, energy, mass, charge, launch angle





The Loss Detector is Sensitive to Trapped and Counter-Passing Orbits





The Loss Detector is Sensitive to Trapped and Counter-Passing Orbits






<u>Caveats</u>


- 1. Full orbit
- 2. No perturbations
- 3. Dist. is naturally in the lost region outside of the scope of NUBEAM



TRANSP Produced Fast Ion Distributions Lack Sufficient Statistics for the Energy Ranges of Interest

- RF-tail produced by NUBEAM/TORIC+RFkick is very small (run with 64000 particles)
- TRANSP distribution must be built up for any meaningful biasing from the reverse integrated dist.










TRANSP Fast Ion Distributions are Improved by Running Stand-Alone NUBEAM/TORIC

- Plasma state file is pulled from TRANSP and ran with the stand-alone version of NUBEAM/TORIC to build the fast ion statistics
- RF-tail is better filled in, but it takes many loops to sufficiently populate higher energies










The NUBEAM Produced Dist. Is Biased Against the Reverse Integrated Dist. to Give Marker Weights

- Randomly sample the NUBEAM distribution in (E, pitch, rho) and bias against the lost distribution to give density markers that can be translated to a particle flux on the detector in a time slice analysis
- Treat the reverse integrated distribution in a binary fashion (existence vs. nonexistence of a lost orbit)
- Requires acceptable "smearing" ranges: 1-2 in rho, 5 in pitch, 10 in energy


Method

- 1. Sample NUBEAM distribution
- 2. Look around the sampled point to reach into the lost region
- 3. Interpolate selected value
- 4. Bias against lost distribution (either 1 or 0)
- 5. Marker weight is noted as density (#/cm³/eV/d ω /4 π)
- 6. Translate weights to particle flux on to detector
- 7. Perform time slice analysis





Can Examine the Differences in Resonances between Fast Ion Species with ORBIT-kick





Conclusions

- The Faraday cup fast ion loss detector on JET has undergone recent upgrades that have resulted in improved acquisition and enhanced measurements
- A model for fast ion transport and confinement, to be validated by measurement, is nearing completion:
 - Constrained equilibria and perturbations via measurement
 - Integrated a synthetic loss detector via biasing distributions
 - Solved statistics problems with NUBEAM/TORIC distributions
 - Calculated ORBIT-kicks for the perturbations



Ongoing & Future Work

Ongoing:

- Adding statistics to TRANSP distribution
- Need to perform final ORBIT run that finds weights for test population
- Calculate fluxes and relate to experimental loss measurements

Future:

- Predictive alpha losses
- "Install" Fataday cups in ORBIT beyond the LCFS
- Extend model to scintillator probe




8/19/20


BACK UP SLIDES




More FILD Loss Measurements

- Deuterium plasmas with MeV scale ICRH heated deuterium NBI ions which act as a proxy for fusion born DT alpha particles
- Fusion products: D+D \rightarrow H³(1.01 MeV)+p(3.02 MeV) and D+He³ \rightarrow He⁴(3.54 MeV)












Finding the q=1 Surface - Results

- SXRT and SXRV are toroidally separated by 135°
- Below is for a single sawtooth
- Zero crossings are approximately R=2.6 m and R=3.4-3.5 m -> Inversion radius
- Second zero crossings are approximately R=2.3-2.4 m and R=3.6-3.8 m -> mixing radius
- Trend appears roughly across all 3 diagnostics












Finding the q=1 Surface - Results Cont.

- Below is for a single sawtooth
- Same results from previous slide translated to ψ_p given by TRANSP equilibrium from (R,Z) coordinates
- Inversion radius -> 0.4
- Mixing radius -> 0.5-0.8 ??
- Using ECE since it's a point diagnostic, there is a big difference between HFS vs, LFS










Fishbones are Decompose into Multiple Modes of Different Frequency

- Fishbones displacements are modeled as simple (1,1) kink modes
- The fishbones are broken up into multiple modes of varying frequency
- Frequency and amplitude are weighted by time


Fishbone Decomposition





*Podestà NucFus 2019

Can Examine the Differences in Resonances between Fast Ion Species with ORBIT-kick





8/19/20